

Dear Partner:

Please note that that **Normal cable(Black)** is the standard item with the shipment of regular SKD-BN screwdrivers.

When pair with the separately purchased countercontrollers, please switch the **Normal cable(Black) with the Anti-Interference cable(white)**

The **Anti-Interference cable(white)** will come along with the shipment of BN Countercontrollers.

Due to many customers used KL-SCBSN & SKP-BC40HL(500W&800W) (V.3.0) & SKP-BC32HL-100(V.3.0) for automation system ,

and some had feedback interference or signal lost issue. Start from 1,

November 2014, KILEWS have included

3 M Anti-Interference cable (white) for model KL-SCBSN & SKP-BC40HL(V.3.0) & SKP-BC40HL-800(V3.0)&SKP-BC32HL-100(V.3.0).

Due to the confusion for Anti-Interference cable(white) and normal cable(black), KILEWS will no longer provide normal cable(Black) with SKD-BN screwdriver when ordering with KL-SCBSN & SKP-BC40HL(V.3.0) & SKP-BC40HL-100(V3.0) &SKP-BC32HL-100(V.3.0)

Loover-Kilews Industrial Co, Ltd.

P.S. Your confirmation of the message by return is necessary for us, thanks for your cooperation